



KAVLICO PRESSURE TANK SENSOR INSTALLATION **INSTRUCTIONS FOR ROYALE COACH**

1. Empty holding tanks completely.
2. In plumbing bay, remove small fiberglass cover near dump valve handles and lower left cover.
3. The black and gray tank sensors will be directly behind the cover – one on the left and one on the right. The sensors will be either gray or black in color and have a black rubber cover with a 6 wire phone cord going into the sensor. The fresh tank sensor can be accessed through the cover near the valves or the lower cover as well. The sensor will look the same as the black and gray sensor.
4. Label the phone cord going into the black and gray sensor with a sharpie or a label so you don't get them mixed up. Then remove the rubber cover and unplug the phone cords from the sensors.
5. Remove the tank sensors from the 3 tanks.
6. Wrap the 3 sensors included in your kit with teflon tape pipe sealant or something suited for sealing PVC pipe. If you are supplied with a bushing adapter, make sure that it is also teflon taped.
7. Install the new tank sensors included in this kit into your holding tanks. Hand tighten and then go no more than a half turn with a wrench or pliers.
8. Plug in the included wiring harness and adapter board to the sensor, then to your existing phone wire in your coach on each tank.